

Hot Work Permit

DIN 6030-4-01

For Maintenance Workers and Outside Contractors at NORTHWEST TECHNICAL COLLEGE

THIS HOT WORK PERMIT IS REQUIRED FOR ANY TEMPORARY OPERATION INVOLVING OPEN FLAMES OR PRODUCING HEAT AND/OR SPARKS. THIS INCLUDES, BUT IS NOT LIMITED TO, BRAZING, CUTTING, GRINDING, SOLDERING, THAWING PIPES, TORCH APPLIED ROOFING, AND WELDING.

PERMIT DATE: / / TIME:	AM PM			
EXPIRES ON: / / TIME:	AM PM			
BUILDING OR AREA:				
ROOM NUMBER AND/OR AREA:				
EQUIPMENT WORKED ON:				
DETECTOR(S) DISABLED? YES NO				
DETECTOR NUMBER(S) AND LOCATION:				
SIGNATURE: NTC PERMIT AUTHORIZING INDIVIDUAL	PRINT NAME:			
SIGNATURE: FIRE WATCH OBSERVER	PRINT NAME:			
SIGNATURE: HOT WORK OPERATOR	PRINT NAME:			
CONTRACTORS COMPANY NAME/ ADDRESS/ CONTACT PHONE:				

THIS PERMIT MUST BE POSTED AT THE WORK SITE.

See Required Precautions Check List on page 2.

The most current documentation is electronic, therefore please discard printed copy after 24 hours.			Print Date: 08/22/19 4:19 PM
Document Number:1001-4-05	Rev. 6/19	Page 1 of 2	Level # 4
Title: Hot Work Permit			Implementation Date: 3-09
Approved: President Hensrud	Date:		

REQUIRED PRECAUTIONS CHECK LIST

GENERAL REQUIREMENTS:

Permit must be complete and signed before any	y work begins
Fire extinguisher, fully charged and operable on site	Permit form must be posted at work site
Hot work equipment/tools in good repair	Fire watch Observer(s) are required
Appropriate smoke detectors covered, and Facilities Servi	ces Supervisor or his designee notified as to the device number(s)
Each hot work operator, at every separate location, require	es a separate permit and fire watch observer.
(If not within 35 feet of each other, in the same room and /	or area, and visible to each other)
REQUIREMENTS WITHIN 35 FEET OF W	ORK:
Floors cleared of readily combustible materials or shielded	d with fire retardant materials and swept clean
Explosive atmosphere in work area eliminated	Flammable chemicals/materials removed or covered
All wall and floor openings covered	Flammable liquids, dust, lint, and oily deposits are removed
WORK ON WALLS OR CEILINGS:	
Construction materials should be non-combustible, and wi	thout combustible covering or insulation
Combustibles moved away from the opposite side of work	area
WORK ON ENCLOSED EQUIPMENT:	
Equipment cleaned of all combustibles and oily residue _	Containers must be purged of flammable liquids and/or vapors
FIRE WATCH OBSERVER:	
Fire watch Observer to post this permit at the work site.	
Fire watch to be provided during and 30 minutes after wor	k including lunch and break times.
Fire watch Observer trained with, and supplied with, an ap	propriate ABC type extinguisher and aware of fire alarm pull stations
Fire watch Observer may be required for both sides of ceil	ling or wall work.
Fire watch Observer is required to notify the Facilities Ser	vices Supervisor or his designee that the work is complete, including
the 30 minute watch period, and make sure that all of the disable	ed or covered heat/smoke detectors have been returned to a
normal operating condition. Return this form at that time.	
Fire watch Observer is required to notify the Facilities Ser	vices Supervisor or his designee of any unusual occurrences during
the work process and/or if additional time may be required for fire	e watch.

The most current documentation is electronic, therefore please discard printed copy after 24 hours.		Print Date: 08/22/19 4:19 PM	
Document Number:1001-4-05	Rev. 6/19	Page 2 of 2	Level # 4
Title: Hot Work Permit			Implementation Date: 3-09
Approved: President Hensrud	Date:		